
Instruction Manual

gone into the design and manufacture of your humidifier. Please read these quality humidifier. The utmost care has instructions and store them in a safe Thank you for your purchase of this place for future reference.






Flame humidifier

FEATURES:

- Timer settings: 30minutes,60minutes,120minutes,180minutes
 Water shortage protection: Auto shut down
- Humidifier spray time: Up to 4 6 hours
- Light: 7 colors LED light
- Water tank capacity: 150ml
- Input interface: Type-C Charging
- Input Voltage: DC 5V == 2A
 Operating current: ≤1300mA
- Power Rating: ≤6.5W



Operating Instructions

- ①Pour the pure water into the water tank along the direction of the sign, and do not exceed the maximum water level.
- ② After powering on, press the button 🖰 to start with the default function (about 10 seconds,the fog will slowly come out from spray jet).
- ③Press the button ♥ to switch the lighting colors
- ②Press the button © to set the timing shutdown, you can choose 30 minutes, 60 minutes, 120 minutes, 180 minutes, the timing indicator of your choice will also light up at the same time, the humidifier shuts down automatically when the timer is reached.
- ⑤Press the button ⊕ to adjust the mist levels, a total of three levels adjustable.

When replacing waste water, the top cover needs to be opened and

dump the waste water in the direction of the pour.

Note: Do not use volatile liquids, such as deodorant, perfume, etc.,

please make sure use water-soluble essential oils.

3After lifting the shell, water can be added. Water must be poured along

with the water position, then essential oil can be added (it must be a water soluble essential oil), no more than 3 drops.

When the water tank is short of water, the humidifier will make a


"beep beep beep" sound and automatically stop working.

①Your "flame humidifier" needs to be equipped with an adapter for use

and output current needs to reach (DC 5V/2A), if your power adapter

does not reach (DC 5V/2A)The flame humidifier may not work properly.

Important Hint



 then drop in water-soluble essential oil (in case of need)

4. Pour the waste water along the sign

Model:HDC2203 Made in China