
Instruction manual

1. Appearance view









2. Hardware description:

- 1. HDMI: HD output
- 2. Mic power support: 5V / 2a, 5V / 1a, 5V / 0.5A
- 3. Handle interface: wired handle, wireless handle,
- one second-hand handle; USB2. 0 Interface
- 4. Indicator light: blue indicator light is on when

- connecting to the power supply
- 5. Support maximum 128g expansion TF Card

3. Function description

- 1. Press the SELECT key on the handle to enter the settings list, language, button tone, search for local files, restore default settings and exit. system information, and exit settings.
- 2. Supported languages: Simplified Chinese, Traditional Chinese, English, and other multiple languages

4. Hardware function definition

4. 1Detailed parameters

Power supply	5V/1A, 5V/2A, 5V/0. 5A				
extend	Support TF card expansion, maximum 128GB				
Video output	HDMI HD output	1			

- 1. The picture of the machine is for reference. The shell of the machine is subject to the material object. The instructions are only for reference. The software upgrade of the machine is subject to the material object.
- 2. If there is any change in the product content or parameters, please refer to the current product without notice.
- 3. The machine is stored in zero files at the factory. All external files (audio, video, games, pictures, etc.) must be deleted immediately after the demonstration. The company will

not take any responsibility for this.

- 4. Charging method: please use the output 5v-la charger, connect the data cable to the USB port of the machine for power
- 5. Executive standard: gb17625.1-2012, gb8898-2011, GB / t13837-2012
- 6. Children between 6.0 and 14 years old need to be accompanied by an adult to use this product.
- 7. Download instructions: please download the game according to the format supported by the machine, and put it in the corresponding folder of the machine

Warranty

- 1. Within seven days from the date of sale, in case of performance failure, the body and package of the goods must be intact, and the same type of goods can be replaced (subject to inspection), but not including artificial damage
- 2. The goods are guaranteed for one year from the date of sale, with lifelong maintenance, and the accessories are not covered by the warranty
- 3. The warranty service is only valid under normal use, and all artificial damages (including self disassembly and improper use) are not covered by the warranty.
- 4. This card shall be provided during warranty. If this card is not provided or altered without permission, the company has the right to scrap it
- 5. This device has no built-in game content, users need to install it by themselves. User should pay attention to the copyright of the content during installation If the disputes or other te, ponsibilities caused by copyright have nothing to do with our company

Packaging accessories								
Color box	machine	USB line	instructions	wireless handle	receiver	HDMI extension cable		
*1	*1	*1	*1	*2	*1	*1		

Product warranty card

User name	Gender	Age	
mailing address			_
contact number		Zip code	
Place of purchase			

Date of purchase	Sales Order No		
Product name and specification	Serial No		
Dealer signature	User signature		



Asphyxiation hazard-all packaging materials (such as WARNING duct tape plastic bags, plastic film, binding wires, labels) and small accessories in the machine should not be exposed to children under 3 years of age to avoid suffocation hazards and should be used under adult supervision

When the ambient temperature is less than or equal to 0 °C, the machine shall be moved indoors and placed at room temperature for 2 hours before use