


## LED Alarm Clock Mirror with Wireless Charging Instruction Manual & Warranty

Thank you for your purchase of this quality clock. The utmost care has gone into the design and manufacture of your clock. Please read these instructions and store them in a safe place for future reference.

### FEATURES:

- 1.4" Colours LED Display
- Wireless Charging
- 4 levels Display Dimmer control
- 4 steps NightLight control (HIGH, MIDDLE, LOW and OFF)
- 9 Minute Snooze
- 4 steps ascending alarm sound
- AC adaptor Output 9V/2A (Included)
- Battery Back up (Battery Included, CR2032)



### POWER SUPPLY

- Insert AC adaptor into a 100 -- 240AC ~ 50/60Hz mains outlet and the other end of cord into the Type-C connection port on the side of the unit.

### SETTING THE TIME

- Press and hold the TIME button approximately 2 seconds to activate Time setting, the LED display flashes to set time.
  - Press the HOUR/+ button to advance to the correct hour. The PM indicator dot will light when the hour is advanced into the PM time.
  - Press the MIN/- button to advance to the correct minute.
  - Press TIME button to confirm and save previous settings, when the correct time is shown on the display, display will now stop flashing.
  - When setting the time, be sure you are in the correct AM or PM time as indicated by the AM or PM indicator on the display.
- NOTE: If you stop setting midway, waiting for 10 seconds to automatically confirm the exit setting.

### SETTING THE ALARM

- Press and hold the ALARM button approximately 2 seconds to activate Alarm setting, the LED display flashes to set alarm time.
  - Press the HOUR/+ button to advance to the correct hour. The PM indicator dot will light when the hour is advanced into the PM time.
  - Press the MIN/- button to advance to the correct minute.
  - Press ALARM button to confirm and save previous settings, when the correct time is shown on the display, display will now stop flashing.
  - When setting the alarm time, be sure you are in the correct AM or PM time as indicated by the AM or PM indicator on the display.
- NOTE: If you stop setting midway, waiting for 10 seconds to automatically confirm the exit setting.

### USING THE ALARM

- Press the ALARM button, the ALARM indicator dot will be lit and the alarm will sound at the preset time.
  - Press the ALARM button again, the ALARM Indicator dot will no longer be visible.
- NOTE: The default is OFF setting.

### USING THE DISPLAY BRIGHTNESS

- While the alarm is not sounding, press the HOUR/+ or MIN/- button to select between 4 levels of brightness.
- NOTE: The default is HIGH setting.

### USING THE NIGHT LIGHT

- While the alarm is not sounding, press the LIGHT button to control the night light.
- There are 4 stages : HIGH, MIDDLE, LOW and OFF.
- NOTE: The default is OFF setting.

### USING THE SNOOZE

- Press the ALARM button to switch ON/OFF the alarm. The ALARM indicator dot will be lit when it is ON.
- When the preset time is reached the alarm will sound for 5 minutes unless one of the following three actions is taken:
  - 1) Press any button to stop the alarm, but the alarm will remain set for the same time the following day.
  - 2) Tap product to enter Sleepy Mode, ALARM indicator will flashing and the alarm will sound again in 9 minutes. This happens every time you tap a product.
  - 3) When entering snooze state, press any button to exit snooze function.

### USING THE WIRELESS CHARGING

- Output : 5W or 10W
- Indicator display :
  - Power connection successful - red and blue light flashes thrice
  - Standby - blue lights on
  - Charging - Blue lights flashing
  - Charged - red and blue lights on
  - FOD - red lights on

### BATTERY BACK UP

- The battery will hold the ALARM and TIME settings if the power is interrupted. If there is no battery and the power is interrupted, the display will 12:00 and the ALARM / TIME will need to be reset.

### CHANGE BATTERY

- Remove the screw from the battery case with a screwdriver ( Phillips head screw driver required, not included ), insert the new CR2032 battery into the battery case, while the positive electrode is upward, insert the cove of battery case into the slot of battery case, tighten the battery case.

### CARE OF YOUR CLOCK

- A soft cloth or a paper towel may be used to clean your clock. Do not use any corrosive cleaner or chemical solutions on the clock. Keep the clock clean and dry to avoid any problems.

### NOTE:

- Do not squeeze or collide.
- Do not disassemble or put into the fire, water, to avoid short-circuit leakage.
- Do not use wireless chargers in severe high temperature, humidity or corrosive environments to avoid leakage of damaged circuits.
- Do not place too close to magnetic cards (ID cards, bank cards, etc) with magnetic strips or chips to avoid magnetic card failure.
- Keep more than 20cm between the implanted medical device (pacemaker, implantable cochlea, etc) and the wireless charger to avoid potential disruption to medical devices.
- Keep children from the product in case they play the wireless charger as a toy to avoid accidents.
- Keep the wireless charger and receiver device away from water and other liquids.
- To clean the charger, make sure the power supply is disconnected.
- Usage temperature : 0 - 45 °C
- Usage humidity : 20 - 85% (40 °C)

### SPECIFICATION

- Input : 9V/2A
- Output power : 10W (Max)
- Charging efficiency : 73%
- Charging distance : ≤5mm

- \* Pictures in this manual are all illustration. Final product is subject to fact.
- \* Inside package : alarm clock, power adapter, manual.

Model : ZH107L  
Printed in China