



Instruction Manual





Thank you for choosing our product
Please read this manual carefully before using it.

FEATURES :

- Cold white and warm white Night light
- Digital Alarm clock
- 9 Minutes Snooze
- Phone wireless charging (10W)
- Apple Watch Wireless Charging (2.5W)
- Airpods plug in charging (5W)





POWER SUPPLY

- Insert the AC adaptor into a 120V AC 60Hz mains outlet and the other end of cord into the DC 9V Jack on the back of the unit.

SETTING THE TIME

- Press and hold TIME button for 2 seconds to activate time setting, The display will flash.
- Press "+" or "-" button to select 12 or 24 hour format, press TIME button to confirm and move to hour setting.
- Press "+" or "-" button to correct hour. The PM indicator will light when the hour is advanced into the PM time.
- Press TIME button to confirm and move to minutes setting.
- When the minutes are flashing, press "+" or "-" button to correct minutes. Press TIME button to confirm and save previous settings. Display will now stop flashing.

DISPLAY BRIGHTNESS

- Press TIME Button to choose 4 levels of display brightness (100%, 60%, 20%, OFF), Default is high.

SETTING THE ALARM TIME

- Press and hold ALARM button for 2 seconds to activate alarm time setting. Hour will flashing.
- Press "+" or "-" button to correct hour. The PM indicator will light when the hour is advanced into the PM time. Press ALARM button to confirm and move to minutes setting.
- When the minutes are flashing, press "+" or "-" button to correct minutes. Press ALARM button to confirm and save previous settings. Display will now stop flashing.

USING THE ALARM

- Press the ALARM button, the ALARM indicator dot will be lit and the alarm will sound at the preset time.
- Press the ALARM button again, the ALARM Indicator dot will no longer be visible.
- The alarm will sound for 5 minute at the programmed time.
- Press any button except the "SNOOZE/LIGHT" button to stop the alarm when it is ringing or snoozing. Alarm will go off on the next day

NOTE: The default is set to OFF.

USING THE SNOOZE

- Press the LIGHT/SNOOZE button after the wake-up alarm sounds will cause the alarm to stop and the alarm will sound again in 9 minutes. This will repeat each time the LIGHT/SNOOZE button is pressed. The snooze indicator will be flash to confirm snooze function is activated.

12 OR 24-HOUR DISPLAY

- In time mode, press and hold the TIME button for 2 seconds to select 12 or 24-HOUR TIME mode.

NOTE: The default is the 12-hour display mode.

NIGHT LIGHT SETTINGS

- While the alarm is not sounding, soft-touch the LIGHT/SNOOZE button to turn on the Night light, touch it again to switch the color from white to amber light.
- Touch the LIGHT/SNOOZE button again to turn off the light.

WIRELESS CHARGE

- That can applicable to phone that support wireless charging.(Iphone 8/8P/SE2/X/XR/XS/XSMax/11/11Pro/11ProMax/12mini/12/12Pro/12ProMax/13mini/13/13Pro/13ProMax/14/14Plus/14Pro/14ProMax)
 - That can applicable to Apple watch 2/3/4/5/6/7/8/SE wireless charging.
 - The charging indicator light is on: it means that the wireless charger is functioning normally.
 - The charging indicator light flashing: Indicates that the charging is abnormal. Please adjust the charging position of your mobile phone to the center until the indicator light is always light.
- Note:** Do not place metal phone cases or metal objects in the wireless charging station.

AIRPODS CHARGE

- Support Plug in Airpod charging

BATTERY WARNING

- Please avoid exposing your clock to direct sunlight.
- Clean the battery contacts and also those of the device prior to battery installation.
- Follow the polarity (+) and (-) to place battery.
- Do not mix old and new batteries.
- Do not mix Alkaline, Standard (Carbon - Zinc), or Rechargeable (Nickel - Cadmium) batteries.
- Incorrect battery placement will damage the clock movement and battery may leak.
- Exhausted battery is to be removed from the product.
- Remove batteries from equipment which is not to be used for an extended period of time.
- Do not dispose of batteries in fire. Batteries may explode or leak.

CARE OF YOUR CLOCK

- A soft cloth or a paper towel may be used to clean your clock. Do not use any corrosive cleaner or chemical solutions on the clock. Keep the clock clean and dry to avoid any problems.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE: This equipment has been tested and found to comply with the limits for Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.